

JACKET

MODEL A-10



MODEL A-10



MODEL DESCRIPTION A-10

- Short jacket, with a semi-fitted line, rounded at the bottom in front. • Shaping darts in front and back. • Wide Mandarin collar. • Sleeve length 4/5, with particular funnel cuff.
- Entire perimeter finished with placket internal.

VERY IMPORTANT FOR THE REALIZATION OF THE MODEL IS TAKING THE MEASUREMENTS.

In the MEASUREMENTS page, selecting “**Show dummy for measures**”, a dummy is displayed.

Selecting a box for entering measurements, for example Person Height, indicates how to correctly take this height.

Your Measurements must be entered as requested, then it is the TittiCad program that processes them so that the original proportions of the model chosen by you adapt to your measurements.

THE A-10 MODEL IS COMPOSED OF FOLLOWING PARTS:

N.1 FRONT. Once on the double fabric.

N.2 FRONT PANEL. Once on the double fabric.

#3 BEHIND. Once on the fabric fold.

N.4 AROUND THE NECK BEHIND. Once on the fabric fold.

N.5 BACK BOTTOM PANEL. Once on the fabric fold.

N.6 NECK. Once on the double fabric.

N.7 SLEEVE. Once on the double fabric.

N.8 CUFF. Once on the double fabric.

N.9 CUFF PANEL. Once on the double fabric.

Note:

The pattern already includes seam allowances.

MATERIAL REQUIRED FOR THE REALIZATION OF THIS MODEL

The fabric used for the model in the photo is a medium weight wool gabardine.

- Recommended fabric: wool or cotton gabardine, denim, cotton twill. **QUANTITY** see following page. • Medium-weight thermo-adhesive cotton canvas for collar and facings.
- Buttons n.5, diameter 2,2 cm. • 1.5 cm wide bias tape, to finish all the internal edges. (Inner edges can always be finished with an overlock stitch or a sewing machine).
- Sewing machine thread.

Being a made-to-measure model, it is not possible to indicate the right quantity for all the materials required.

You will have to measure it appropriately.

PATTERN ON FABRIC AND QUANTITY OF FABRIC NECESSARY

There are 2 possible cases, depending on whether you are using the TittiCad Program (installed on your PC), or the Online Pattern Making Service (present on the website www.titticad.com):

- TittiCad program: By opening the PRINT page and selecting the **Arrangement on fabric** item from the "List of Available Prints", a suggestion is displayed on how to position the model on the fabric.

- [Online Patterns of www.titticad.com](http://www.titticad.com): After entering the measurements and requesting the Free Preview, it is shown at the bottom of the page **Arrangement on fabric and required fabric length**.

The vertical arrow indicates the quantity of fabric required, while the horizontal arrow indicates the width of the fabric, it can be double fabric (when 75cm is indicated) or single fabric (when 150cm is indicated).

It is recommended to always take a little more (10-15 cm)

PACKAGING TIPS

Pattern preparation

[How to assemble TittiCad pattern.](#)

First steps in the packaging

[2-3 Things to know about fabric before placing pattern on fabric.](#)

[How to place pattern on fabric.](#)

[Mark the outline of the pattern and assemble a front with a back.](#)

Specific video tutorials for this model

- Sew all darts:

[Sew simple darts.](#)

[Sew diamond darts.](#)

- Join the front with the back.
- Finish all inside edges with bias tape or overlock stitch.

- Apply thermo-adhesive cloth to all the facings and to the inner collar. • [How to apply thermoadhesive cloth.](#)

- Sew together the facings on the front with the 2 on the back.

- Apply collar and facings to jacket.

[Sew Mandarin collar 1.](#)

- Finish the edges with bias or overlock stitch free of the facings.

[How to apply bias tape on placket.](#)

- Sew the sleeves with its cuffs, finish them and close the sleeve.

- Apply the cuff facing, after having it closed in a ring.

- Sew sleeve to bodice: [Sew sleeve](#)

[around.](#)

For all the video tutorials on the pack, click the link below:

www.titticad.com/package