

# BAG WITH HANDLES

**MOD-A-48**



## MOD-A-48



# MOD-A-48

## **DESCRIPTION MOD-A-48**

It is a bag with handles, lined.

Internally it has a zipped pocket and a patch pocket.

Carabiner for keys, applied with ribbon caneté on the upper edge of the bag.

The dimensions of the bag are up to you to decide, entering only one measurement, namely the height.

The TittiCad program will take care of the various calculations from execute to ensure that the shape is the same of the photo, but with different dimensions, maintaining so the proportions.

**IT IS VERY IMPORTANT FOR THE CREATION OF THE MODEL TO INSERT THE REQUIRED MEASUREMENTS CORRECTLY.**

**Then it is the TittiCad program that processes them so that the original proportions of the model chosen by you adapt to your entered measurements.**

**Always be careful after inserting the measurements, that the model is harmonious.**

## **THE MOD-A-48 IS COMPOSED OF FOLLOWING PARTS:**

**N.1 FRONT - BACK.**

**N.2 SIDE.**

**N.3 HANDLES.**

**N.4 INTERNAL APPLIED POCKET.**

**N.5 POCKET BAG.**

**N.6 POCKET BAG.**

**For the external part, the paper patterns are used: N.1**

Once on the double fabric.

**N.2** Once on the double fabric.

**N.3** Once on the double fabric

**For the internal part, the paper patterns are used: N.1**

Once on the double fabric.

**N.2** Once on the double fabric.

**For the pockets, the following paper patterns**

**are used: N.4** Once on the single fabric.

**N.5** Once on the single fabric.

**N.6** Once on the single fabric.

### **Note:**

The pattern already includes seam allowances.

## **MATERIAL REQUIRED FOR CREATION OF THIS MODEL**

The fabric used for the model in the photo is home furnishing fabric.

For the outside: a hemp-cotton blend.

For the inside and pockets, cotton.

- **QUANTITY** see next page.
- Sewing machine thread.
- Grosgrain ribbon 1.5 cm high, 15-20 cm long.
- 4 cm long carabiner.
- Zipper.

Being a model with variable sizes, it is not possible to indicate the right quantity for all the materials needed.

You will have to measure them appropriately.

## **PATTERN ON FABRIC AND QUANTITY OF STUFF REQUIRED**

There are 2 possible cases, depending on whether you are using the TittiCad Program (installed on your PC), or the Online Pattern Service (present on the website [www.titticad.com](http://www.titticad.com)):

- TittiCad program:

By opening the PRINT page and selecting the **Layout on fabric** item in the “Available Print List”.

a suggestion of how to place the pattern on fabric appears.

- [Online paper patterns from www.titticad.com](http://www.titticad.com):

After entering the measurements and requesting the Free Preview, the **Arrangement on fabric and required fabric length is shown at the bottom of the page.**

The vertical arrow indicates the quantity of fabric needed, while the horizontal arrow indicates the width of the fabric, it can be double fabric (when 75cm is indicated) or single fabric (when 150cm is indicated).

It is recommended to always take a little more (10-15cm)



## **PACKAGING TIPS**

### **Paper pattern preparation**

[How to assemble TittiCad paper pattern.](#)

### **First steps in packaging**

[2-3 Things to know about fabric before placing paper pattern on fabric.](#)

---

[How to place paper pattern on fabric.](#)

[Mark the outline of the paper pattern and assemble the front and back.](#)

### **Video tutorials specific to this model**

[MOD-A-48 Bag with handles. Complete package.](#)

[Zippered pocket.](#)

For all video tutorials on packaging click the link below: [www.titticad.com/confezione](http://www.titticad.com/confezione)

---